## RS507

|                   | RS507 Hands-Free Imager with DL focus, a 2-finger mounted barcode imager           |
|-------------------|--|
| RS507-DL200000TWR | with manual trigger and without a battery. Requires battery.                       |
|                   | RS507 Hands-Free Imager with DL focus, a 2-finger mounted barcode imager           |
|                   | with manual trigger and corded adaptor to the WT4090 wearable terminal.            |
| RS507-DL20000CTWR | Requires extended capacity battery for the WT4090.                                 |
|                   | RS507 Hands-Free Imager with DL focus, a 2-finger mounted barcode imager           |
|                   | without trigger for auto-triggering using the Intelligent Sensing Technology (IST) |
| RS507-DL20000ENWR | with extended capacity battery for Bluetooth interface to supported mobile         |
|                   | RS507 Hands-Free Imager with DL focus, a 2-finger mounted barcode imager           |
|                   | without trigger for auto-triggering using the Intelligent Sensing Technology (IST) |
| RS507-DL20000SNWR | with standard capacity battery for Bluetooth interface to supported mobile         |
|                   | RS507 Hands-Free Imager with DL focus, a 2-finger mounted barcode imager           |
| RS507-DL20000STWR | with manual trigger and standard capacity battery for cordless Bluetooth           |
|                   | RS507 Hands-Free Imager. 2-Finger mounted barcode imager with manual               |
|                   | trigger; without a battery or a corded adaptor to the WT4090 wearable terminal.    |
| RS507-IM200000TWR | Requires either a battery or a corded adaptor (neither included).                  |
|                   | RS507 Hands-Free Imager. a 2-finger mounted barcode imager with manual             |
| RS507-IM20000CTWR | trigger and corded adaptor to the WT4090 wearable terminal. Requires extended      |
|                   | RS507 Hands-Free Imager, a 2-finger mounted barcode imager without manual          |
|                   | trigger for auto-triggering using the Intelligent Sensing Technology (IST) with    |
| RS507-IM20000ENWR | extended capacity battery for Bluetooth interface to supported mobile computer     |
|                   | RS507 Hands-Free Imager, a 2-finger mounted barcode imager without manual          |
|                   | trigger for auto-triggering using the Intelligent Sensing Technology (IST) with    |
| RS507-IM20000SNWR | standard capacity battery for Bluetooth interface to supported mobile computer     |
|                   | RS507 Hands-Free Imager, a 2-finger mounted barcode imager with manual             |
| RS507-IM20000STWR | trigger and standard capacity battery for cordless Bluetooth interface to          |